

Press the button to play 358 automatically The effect. Press 5 times to enter RGB color jump mode Convenient lamp test.

## Mode+(358 modes)

## Brightness+

To adjust the number of LED pixel points and the RGB order:Long press 5 seconds to enter the setup menu and Press MODE+ and MODE- to adjust the LED points, 32 points at a time.Press RGB button to adjust RGB sequence, press R until the light bar shows red, press G until the light bar shows green, press B until the light bar shows blue, press this button to exit after adjustment.

Static monochrome mode