

I. Q2-WY wireless panel description



II. Instructions for using

2.1 Matching: Switch off the power, then switch on power again, short press the middle key "⏻" 3 times on the panel quickly within 5s after Lighting power on, the link is done once the light blinks 3 times.

2.2 Deleting: Switch off the power, Long press the middle "⏻" key about 6s, (Hold on your hands on the key don't move until the light flash 3 times) then switch on power again, the unlink is done once the light blinks 3 times.

2.3 Brightness adjustment: Press the "◀BRT-" key on the upper left corner to minus bright of the lamp. Press the "BRT+▶" key on the upper right corner to add bright of lamps.

2.4 Adjust the color temperature: Slide the circular color slider in the middle to adjust the color temperature of the lamps.

2.5 Scenario Preservation: When the brightness and color temperature of the lamp are adjusted to the required value, long press the "📄" key for about 5 seconds, and the light blink once. The brightness and color temperature of the current lamp can be saved as a scene and then clicked again after the scene is saved. The brightness and color temperature of the lamp can be switched to the saved scenario. You can save up to two scenarios.

Product parameters

Product type: Q2-WY product size: 86*88*7mm

Way of power supply: CR2032 button cell

Standby time: About 6000 hours

Control distance: ≤50m

RF Frequency band: 2.4 GHz-2.483 GHz